# Alpha-Basis 24 V AB 4001-6 / AB 4001-1

Alpha-Basis 24 V is a connection unit for connecting the room thermostats (e. g. OEM-Thermostats) to the actuators (e. g. OEM-Actuators). Furthermore, the Alpha-Basis provides the operation voltage for the connected devices.

Predominantly, it is used at the heating circuit distributor of a floor heating. The Alpha-Basis is appropriate for new constructions, as well as for the re-fitting of residential and commercial buildings with already existing floor heating

In order to adapt the heating system individual to requirements, various extension modules (e. g. TimerModule) can be connected to the integrated interface of the Alpha-Basis. This modular structure allows an extension of the Alpha-Basis at any time. The spring/clamp connections minimize installation time.



#### **Features**

- Operating mode indicators (voltage supply, fuse)
- Function indicator (operating condition of thermostats)
- Connection by screwless spring/clamp terminal connection
- Clear arrangement of the connection line with cable grip
- Extendible modular
- Also available as 1-room basis

### **General Information**

#### Type Designation

AB 4001-6 for max. 6 room thermostat AB 4001-1 for max. 1 room thermostat

#### Scope of Supply

- 1 x Alpha-Basis 24 V , including transformer
- 1 x Manual
- 2 x 2 screws
- 4 x Distance sleeves

# Accessories

Program plug AB PS 4000 (optional)

# **Extension Options**

- ActuatorModule AM 4000 Heating/CoolingModule HK 4000
- PumpModule PL 4000
- PumpDoubleModul PD 4000
- Thermostat Module RM 4000
- TimerModule TM 1000

#### **Connection Recommendations**

- OEM-Thermostat R 4..OEM-Actuator A 4004

#### **Ordering Information**

Our staff will be glad to assist you in finding the Alpha-Basis fitting your application. Call us at: +49 - 53 41 - 84 75 - 0

### **Application & Function**

The Alpha-Basis 24 V is applied for the installation of floor heating systems in new constructions or in the modernisation of privately owned residences, office buildings, multipurpose halls, and also for modernising and refitting older buildings.

In most cases, the Alpha-Basis is mounted in the heating circuit distribution cabinet, directly on the wall, or on a mounting bracket. It is designed for the installation of 6 room thermostats (e. g. OEM-Thermostats) and a total of 14 actuators (e.g. OEM-Actuators).

The screwless and colour-coded connection technique (spring/clamp terminal connection) allows simple and quick installation. All electrical lines are secured with cable grips. The guides of the cable grips as well as the clear arrangement allow a trouble-free and quick installation of the Alpha-Basis.


Control displays inform the user about the operating state of the thermostats, the operating voltage and the fuse state.

The integrated interface allows the extension of the Alpha-Basis with optionally available modules. The TimerModule, for example, in particular in connection with the Alpha-Thermostats Standard and Comfort, allows automatic temperature setback using two separate heating programs.


The entire 24 V control system is marked by easy installation, enormous system security and high controlling comfort. It allows a precise and comfortable temperature control in different heating zones within a building.

# The Alpha-System 24 V

### **Extension Options**



#### **Connection Recommendations**





### **Technical Data**

Туре	AB 4001-6	AB 4001-1	
Operating voltage	230 V / 24 V AC secondary	230 V / 24 V AC secondary	i₄ 302 ▶i
Max. power input	50 W	50 W	<b>A</b>
Fuse	T 2A H	T 2A H	70
Max. number of thermostats	6	1	
Max. number of actuators (about 2 W)	14	4	(AB 4001-6)
Heating programs, optional	2	2	(1.2.1007.0)
Dimensions (mm) H/W/L	70 / 75 / 302	70 / 75 / 157	4 157 → 4 75 →
Weight, including transformer	1.700 g	1.350 g	^
Protection class	II	II	70 70
Protection type	IP 20	IP 20	
Ambient temperature	0 to 50°C	0 to 50°C	(AB 4001-1)
Storage temperature range	-25 to 60°C	-25 to 60°C	
Relative humidity	max. 80% <sup>1)</sup>	max. 80% <sup>1)</sup>	( F
Applicable wire sections			1) not condensing
Solid wire	0.5 – 1.5 mm <sup>2</sup>	0.5 – 1.5 mm <sup>2</sup>	2) The wires of the actuators can be used with factory-
Flexible wire <sup>2)</sup>	1.0 – 1.5 mm <sup>2</sup>	1.0 – 1.5 mm <sup>2</sup>	mounted end sleeves.

Please take information on the start-up and on the controlling operation from the manual included in the scope of delivery.

### **Planning and Installation Notes**

# **Connection of Room Temperature Thermostats**





















# **Heating Programs**

In connection with the Alpha-Thermostat Standard or Comfort and the TimerModule, an automatic temperature setback is possible, using two separated heating programs.



Easy programming of heating periods using the TimerModule

#### Note:

Please consider that a proper function of the Alpha-Basis with the TimerModule is only possible in conjunction with the Alpha-Thermostats Standard and Comfort.

# **Product Overview Alpha-Basis Connection System**

### Devices

The Alpha-Basis consists of a flexible and broad product portfolio. Following versions are available:

Alpha-Basis 230 V	AB 2000-1 / AB 2000-6
Alpha-Basis 24 V	AB 4001-1/ AB 4001-6
Alpha-Basis RC 868 MHz	AB 4071-6 / AB 4071-12
Alpha-Basis EIB	AB 7001-6 / AB 7001-12

Alpha-Basis	Matrix					
AB 2000	•		•	•	•	•
AB 4001	•	•	•	•	•	•
AB 4071		•	•	•		•
AB 7001	•		•	•		
	00000000	000± 1/1	OD TO S	OD OD ON THE	OO DE	000 41

Phone +49 53 41 · 8475-0

+49 53 41 · 8475-999